

## Assembly Instruction For 22106

- 1. Put the upper parts on the connector, then secured it
- 2. Screw the loop on the nipple 1.
- 3.Attach the glass and metal ring on the socket, then secure by the socket ring.

